


Operation Guide 5374/5392


CASIO®

- Your watch may differ somewhat from the one shown in the illustration.




Crown Operations

Some water-resistant models (100 meters, 200 meters) have a screw-in crown. When you need to perform a crown operation, rotate it towards you to unscrew it. Then pull the crown out. Avoid applying undue force when pulling. The watch loses its water resistance while the crown is unscrewed. After performing a crown operation, fully screw the crown back in.



If your watch has a rotary bezel...

You can rotate the bezel to align its ▼ mark with the minute hand. Then you will be able to tell how much time has elapsed since aligning the ▼ mark.



To adjust the time setting

When the second hand is at 12 o'clock, pull the **Crown** out.

Rotate the **Crown** to change the time setting.

Push the **Crown** back in.

Note

- Take care that you set the correct AM or PM time.
- When changing the time, move the minute hand four or five minutes past your final setting, and then back it up to the setting you want.
- The 24-Hour Hand indicates the current hour of the day. It makes one complete rotation every 24 hours.

To change the day and day of the week settings

Press **(B)** to change the day and **(A)** to change the day of the week.

Note

- The day setting uses a 31-day month. Make adjustments for months of shorter lengths.
- Avoid changing the day and day of the week settings between the hours of 9 p.m. and 4 a.m. Otherwise, the day and day of the week may not change correctly at midnight.

Specifications

Accuracy: ±20 seconds average per month

Battery: One silver oxide battery (Type: SR927SW)

Battery Life: Approximately 3 years