

MIYOTA

UNIVERSAL MASTERPIECE BORN IN JAPAN

MADE IN JAPAN

METAL MOVEMENT

INSTRUCTION MANUAL FOR MIYOTA WATCH MOVEMENT

CALIBRE NO. 82S0

AUTOMATIC MOVEMENT WITH FRONT VIEW SKELETON

A) DISPLAYS AND BUTTONS

B) WINDING THE MAINSPRING

C) SETTING THE TIME

A) DISPLAYS AND BUTTONS



B) WINDING THE MAINSPRING

Automatic winding watch can also be hand wound by turning the crown clockwise in Normal position. Wind several times clockwise. It will start to move naturally.

C) SETTING THE TIME

1. Pull the crown out to the 1st Click Position.
2. Turn the crown to set hour and minute hands.
3. After the time has been set, push the crown back to the Normal position.

These specifications might be changed without prior notice.

CITIZEN WATCH CO., LTD.

MIYOTA

诞生于日本的世界通用机械机芯
日本制造
金属机芯

MIYOTA机心操作手册
型号 82S0
自动机械机芯(半镂空)

- A) 显示和按钮
- B) 上发条
- C) 校时

A) 显示和按钮



B) 上发条

自动表也可以通过手动上发条, 顺时针转动位于正常位置的柄头即可
手动上条的话一般顺时针转几下, 就开始走针

C) 校时

1. 将柄头拉至一档位置。
2. 转动柄头调整时针和分针。
3. 调整后, 把柄头推回通常位置。

上述数值如有变更恕不另行通知

CITIZEN WATCH CO., LTD.